

## **Lab 2 :- Networking Commands Lab File**

- **AIM**

1. To study and execute various Windows networking commands such as arp -a, hostname, ipconfig, ipconfig/all, ipconfig/renew, ipconfig/release, ipconfig/flushdns, nbtstat -a, netdiag, netstat, nslookup, pathping, ping, route, and tracert to understand their functionality in troubleshooting and managing network configurations.

- **SOFTWARE REQUIRED**

1. Operating System: Windows (Windows 7/10/11)
2. Command Prompt (cmd.exe)
3. Internet connectivity (for external commands like ping, tracert, nslookup)

### **THEORY**

1. **arp -a** → Displays the Address Resolution Protocol (ARP) cache, showing the mapping between IP addresses and MAC addresses.
2. **hostname** → Displays the computer's hostname (system name).
3. **ipconfig** → Displays basic network configuration details like IP address, subnet mask, default gateway.
4. **ipconfig /all** → Displays detailed configuration including MAC address, DHCP, DNS, etc.
5. **ipconfig /renew** → Requests a new IP address from the DHCP server.
6. **ipconfig /release** → Releases the current IP address obtained from DHCP.
7. **ipconfig /flushdns** → Clears DNS cache, useful when DNS entries are outdated.
8. **nbtstat -a <hostname>** → Displays NetBIOS over TCP/IP statistics, helps in finding remote system's NetBIOS name table.
9. **netdiag** → (Older Windows tool) Tests network connectivity and configuration issues.
10. **netstat** → Displays active TCP/UDP connections, ports, and network statistics.
11. **nslookup** → Queries DNS servers to resolve domain names into IP addresses.
12. **pathping <destination>** → Combines ping and tracert to show packet loss and latency at each hop.
13. **ping <destination>** → Tests connectivity to another host and measures round-trip time.
14. **route print** → Displays the system's routing table.
15. **tracert <destination>** → Traces the route packets take to a destination host.

### **COMMANDS EXECUTED ON CMD**

```
C:\Users\LAB 102 PC 30>arp -a
```

Interface:	192.168.56.1 --- 0x2	
Internet Address	Physical Address	Type
192.168.56.255	ff-ff-ff-ff-ff-ff	static
224.0.0.22	01-00-5e-00-00-16	static
224.0.0.251	01-00-5e-00-00-fb	static
224.0.0.252	01-00-5e-00-00-fc	static
239.255.255.250	01-00-5e-7f-ff-fa	static

  

Interface:	192.168.0.145 --- 0xd	
Internet Address	Physical Address	Type
192.168.0.1	30-de-4b-a3-2a-e0	dynamic
192.168.0.120	84-69-93-84-24-5d	dynamic
192.168.0.124	d0-c6-37-64-48-08	dynamic
192.168.0.153	84-69-93-79-c5-a5	dynamic
192.168.0.221	84-69-93-79-bf-fc	dynamic
192.168.0.255	ff-ff-ff-ff-ff-ff	static
224.0.0.22	01-00-5e-00-00-16	static
224.0.0.251	01-00-5e-00-00-fb	static
224.0.0.252	01-00-5e-00-00-fc	static
239.255.255.250	01-00-5e-7f-ff-fa	static
255.255.255.255	ff-ff-ff-ff-ff-ff	static

```
C:\Users\LAB 102 PC 30>hostname  
DESKTOP-VSLPBKE
```

```
PS C:\Users\LAB 102 PC 30> pathping
```

```
Usage: pathping [-g host-list] [-h maximum_hops] [-i address] [-n]
                 [-p period] [-q num_queries] [-w timeout]
                 [-4] [-6] target_name
```

Options:

-g host-list	Loose source route along host-list.
-h maximum_hops	Maximum number of hops to search for target.
-i address	Use the specified source address.
-n	Do not resolve addresses to hostnames.
-p period	Wait period milliseconds between pings.
-q num_queries	Number of queries per hop.
-w timeout	Wait timeout milliseconds for each reply.
-4	Force using IPv4.
-6	Force using IPv6.

```
C:\Users\LAB 102 PC 30>ipconfig/release
```

Windows IP Configuration

Ethernet adapter Ethernet:

```
Connection-specific DNS Suffix . :
Link-local IPv6 Address . . . . . : fe80::1ea2:efa6:9c5:8ade%13
Default Gateway . . . . . :
```

Ethernet adapter Ethernet 3:

```
Connection-specific DNS Suffix . :
Link-local IPv6 Address . . . . . : fe80::5f51:5541:44b2:aaac%2
IPv4 Address. . . . . : 192.168.0.145
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . :
```

```
C:\Users\LAB 102 PC 30>ipconfig/renew
```

Windows IP Configuration

Ethernet adapter Ethernet:

```
Connection-specific DNS Suffix . :
Link-local IPv6 Address . . . . . : fe80::1ea2:efa6:9c5:8ade%13
IPv4 Address. . . . . : 192.168.0.145
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.0.1
```

Ethernet adapter Ethernet 3:

```
Connection-specific DNS Suffix . :
Link-local IPv6 Address . . . . . : fe80::5f51:5541:44b2:aaac%2
IPv4 Address. . . . . : 192.168.56.1
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . :
```

```
::\Users\LAB 102 PC 30>nslookup
Default Server: Unknown
Address: fec0:0:0:ffff::1
```

```
C:\Users\LAB 102 PC 30>ipconfig
```

Windows IP Configuration

Ethernet adapter Ethernet:

```
Connection-specific DNS Suffix . . .
Link-local IPv6 Address . . . . . : fe80::1ea2:efa6:9c5:8ade%13
IPv4 Address. . . . . : 192.168.0.145
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.0.1
```

Ethernet adapter Ethernet 3:

```
Connection-specific DNS Suffix . . .
Link-local IPv6 Address . . . . . : fe80::5f51:5541:44b2:aaac%2
IPv4 Address. . . . . : 192.168.56.1
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . :
```

```
C:\Users\LAB 102 PC 30>netdiag
```

```
'netdiag' is not recognized as an internal or external command,
operable program or batch file.
```

```
C:\Users\LAB 102 PC 30>net diag
```

The syntax of this command is:

NET

```
[ ACCOUNTS | COMPUTER | CONFIG | CONTINUE | FILE | GROUP | HELP |
HELPMSG | LOCALGROUP | PAUSE | SESSION | SHARE | START |
STATISTICS | STOP | TIME | USE | USER | VIEW ]
```

```
%{
#include <stdio.h>
int line_count = 0, word_count = 0, capital_letters = 0, small_letters = 0;
int numbers_10_21 = 0, digits_0_9 = 0, special_chars = 0, delimiters = 0;
int relational_operators = 0, total_chars = 0;
%}

%#
\n
{ line_count++; total_chars++; }
[ \t]+
{ }
[a-z]
{ small_letters++; total_chars++; }
[A-Z]
{ capital_letters++; total_chars++; }
[0-9]
{ digits_0_9++; total_chars++; }
(10|21)
{ numbers_10_21++; total_chars += 2; }
[;...]
{ delimiters++; total_chars++; }
[!@#$%^&*()_+=<>?/\\"|\{\}\[\]\~`]
{ special_chars++; total_chars++; }
(==|=|<|=|>|=|<|>)
{ relational_operators++; total_chars += yylen; }
[^ \t\n]
{ word_count++; total_chars++; }
```

```
int main()
printf("Enter the text (Press CTRL+D to end input):\n");
yylex();
printf("\nStatistics:\n");
printf("Lines: %d\n", line_count);
printf("Words: %d\n", word_count);
printf("Capital Letters: %d\n", capital_letters);
printf("Small Letters: %d\n", small_letters);
printf("Numbers (10,21): %d\n", numbers_10_21);
printf("Digits (0-9): %d\n", digits_0_9);
printf("Special Characters: %d\n", special_chars);
printf("Delimiters: %d\n", delimiters);
printf("Relational Operators: %d\n", relational_operators);
printf("Total Characters: %d\n", total_chars);
return 0;
```

```
int yywrap()
{
    return 1;
}
```

```
- route delete 0.0.0.0/0
```

```
PS C:\Users\LAB 102 PC 30> tracert
```

  

```
Usage: tracert [-d] [-h maximum_hops] [-j host-list] [-w timeout]
                [-R] [-S srcaddr] [-4] [-6] target_name
```

Options:

-d	Do not resolve addresses to hostnames.
-h maximum_hops	Maximum number of hops to search for target.
-j host-list	Loose source route along host-list (IPv4-only).
-w timeout	Wait timeout milliseconds for each reply.
-R	Trace round-trip path (IPv6-only).
-S srcaddr	Source address to use (IPv6-only).
-4	Force using IPv4.
-6	Force using IPv6.

```
PS C:\Users\LAB 102 PC 30> 6
```

```
6
```

```
PS C:\Users\LAB 102 PC 30> |
```

If the command is PRINT or DELETE. Destination or gateway can be a wildcard, (wildcard is specified as a star '\*' ), or the gateway argument may be omitted.

If Dest contains a \* or ?, it is treated as a shell pattern, and only matching destination routes are printed. The '\*' matches any string, and '?' matches any one char. Examples: 157.\*.1, 157.\*, 127., \*224\*.

Pattern match is only allowed in PRINT command.

Diagnostic Notes:

    Invalid MASK generates an error, that is when (DEST & MASK) != DEST.

    Example> route ADD 157.0.0.0 MASK 155.0.0.0 157.55.80.1 IF 1

        The route addition failed: The specified mask parameter is invalid. (Destination & Mask) != Destination.

Examples:

```
> route PRINT
> route PRINT -4
> route PRINT -6
> route PRINT 157*      .... Only prints those matching 157*
> route ADD 157.0.0.0 MASK 255.0.0.0 157.55.80.1 METRIC 3 IF 2
    destination^      ^mask        ^gateway      metric^      ^
                                         ^Interface^
    If IF is not given, it tries to find the best interface for a given
    gateway.
> route ADD 3ffe::/32 3ffe::1

> route CHANGE 157.0.0.0 MASK 255.0.0.0 157.55.80.5 METRIC 2 IF 2
    CHANGE is used to modify gateway and/or metric only.

> route DELETE 157.0.0.0
> route DELETE 3ffe::/32
```

PS C:\Users\LAB 102 PC 30> **route**

Manipulates network routing tables.

**ROUTE [-f] [-p] [-4|-6] command [destination]**  
                              [MASK netmask] [gateway] [METRIC metric] [IF interface]

**-f**       Clears the routing tables of all gateway entries. If this is used in conjunction with one of the commands, the tables are cleared prior to running the command.

**-p**       When used with the ADD command, makes a route persistent across boots of the system. By default, routes are not preserved when the system is restarted. Ignored for all other commands, which always affect the appropriate persistent routes.

**-4**       Force using IPv4.

**-6**       Force using IPv6.

**command**   One of these:

    PRINT     Prints a route  
    ADD       Adds a route  
    DELETE    Deletes a route  
    CHANGE    Modifies an existing route

**destination**   Specifies the host.

**MASK**       Specifies that the next parameter is the 'netmask' value.

**netmask**     Specifies a subnet mask value for this route entry.

If not specified, it defaults to 255.255.255.255.

**gateway**     Specifies gateway.

**interface**   the interface number for the specified route.

**METRIC**     specifies the metric, ie. cost for the destination.

All symbolic names used for destination are looked up in the network database file NETWORKS. The symbolic names for gateway are looked up in the host name database file HOSTS.

PS C:\Users\LAB 102 PC 30> **ping**

Usage: ping [-t] [-a] [-n count] [-l size] [-f] [-i TTL] [-v TOS]  
                              [-r count] [-s count] [[-j host-list] | [-k host-list]]  
                              [-w timeout] [-R] [-S srcaddr] [-c compartment] [-p]  
                              [-4] [-6] target\_name

Options:

<b>-t</b>	Ping the specified host until stopped. To see statistics and continue - type Control-Break; To stop - type Control-C.
<b>-a</b>	Resolve addresses to hostnames.
<b>-n count</b>	Number of echo requests to send.
<b>-l size</b>	Send buffer size.
<b>-f</b>	Set Don't Fragment flag in packet (IPv4-only).
<b>-i TTL</b>	Time To Live.
<b>-v TOS</b>	Type Of Service (IPv4-only. This setting has been deprecated and has no effect on the type of service field in the IP Header).
<b>-r count</b>	Record route for count hops (IPv4-only).
<b>-s count</b>	Timestamp for count hops (IPv4-only).
<b>-j host-list</b>	Loose source route along host-list (IPv4-only).
<b>-k host-list</b>	Strict source route along host-list (IPv4-only).
<b>-w timeout</b>	Timeout in milliseconds to wait for each reply.
<b>-R</b>	Use routing header to test reverse route also (IPv6-only). Per RFC 5095 the use of this routing header has been deprecated. Some systems may drop echo requests if this header is used.

## RESULT

- Successfully executed and observed outputs of all the above networking commands.
- Understood the usage of each command for **network diagnosis, troubleshooting, and configuration**.

## CONCLUSION

- This lab demonstrated practical knowledge of fundamental networking commands available in Windows. These commands are essential for diagnosing network problems, verifying configurations, and ensuring connectivity between systems. Regular practice of these commands improves troubleshooting skills and strengthens understanding of computer networks.